









Thank you for purchasing your Original Racquet Butt Kit by Racquet Art. If you have any questions, please feel free to email us at info@racquetart.com. Below are the instructions for installing the butt kit on your racquet. We recommend having your local pro-shop install the actual cap on the racquet. Change the look of your butt as often as you would like by replacing the crystal dome sticker. Visit www.racquetart.com for additional crystal dome stickers, adhesive discs, stencils and inks.



Eight Steps to Give Your Racquet a Great Butt!

<p>Step 1 Remove overgrip, if any, and grip from the racquet carefully. The grip will be reapplied later in the installation of the new butt cap. The picture below shows a racquet with the grip removed.</p> 	<p>Step 2 Using a small spade screwdriver, loosen the staples that are holding the old butt cap to the racquet handle. Be careful not to damage the racquet. The staples will need to be loosened enough to grip with a plier as shown in Step 3.</p> 	<p>Step 3 Remove and discard all of the staples using a pair of pliers. After the staples are removed, slide the cap from the racquet handle.</p> 	<p>Step 4 Slide the new butt cap from the kit over the handle of the racquet. Ensure that the handle of the racquet is inserted all the way into the new butt cap. Using a staple gun, staple the new cap to the racquet handle on all four sides.</p> 
<p>Step 5 Reapply the old or a new grip to the racquet covering the new butt cap.</p> 	<p>Step 6 Remove the backing from the crystal dome sticker and apply to front of the picture making sure it is centered in the dome. The picture should be visible through the crystal dome sticker.</p> 	<p>Step 7 Next, remove the backing from one side of the special adhesive disc and apply to the back of the picture that now has the dome sticker attached.</p> 	<p>Step 8 Lastly, remove the backing from the second side of the adhesive disc and apply the newly assembled dome sticker and picture to the new butt cap on the racquet.</p> 

Be sure to visit us at www.racquetart.com for additional art for your racquet.